Always there to help you

Register your product and get support at
www.philips.com/support

BT4000

Question? Contact Philips

User manual

PHILIPS

Contents

1 Important 2

2 Your Bluetooth speaker 3
Introduction 3
What's in the box 3
Overview of the speaker 4

3 Get started 5
Connect power 5
Turn on 5
Turn off 5

4 Use Bluetooth devices 6
Connect a device 6
Play from Bluetooth device 7
Control your phone call 7
Disconnect the Bluetooth-enabled device 7
Connect another Bluetooth-enabled device 7
Reconnect the Bluetooth device 7

5 Other features 8
Listen to an external device 8
Charge your mobile devices 8
Adjust volume 8

6 Product information 9
Specifications 9

7 Troubleshooting 10
General 10
About Bluetooth device 10

8 Notice 11
Compliance 11
Care of the environment 11
Trademark notice 11

1 Important

Warning

- Never remove the casing of this speaker.
- Never lubricate any part of this speaker.
- Never place this speaker on other electrical equipment.
- Keep this speaker away from direct sunlight, naked flames or heat.
- Make sure that you always have easy access to the power cord, plug, or adaptor to disconnect the speaker from the power.

- Make sure that there is enough free space around the speaker for ventilation.
- Use only power supplies listed in the user manual.
- The speaker shall not be exposed to dripping or splashing.
- Do not place any sources of danger on the speaker (e.g. liquid filled objects, lighted candles).
- Where the plug of the Direct Plug-in Adapter is used as the disconnect device, the disconnect device shall remain readily operable.

Note

- The type plate is located on the bottom of the product.

2 Your Bluetooth speaker

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Introduction

With this speaker, you can

- enjoy audio from your Bluetooth-enabled devices, or other external audio devices; and
- charge your mobile devices.

What's in the box

Check and identify the contents of your package:

- Speaker
- Power adapter
- Short user manual
- Safety and notice leaflet

Overview of the speaker



1 ⏻
- Turn the speaker on or off.

2 +/-
- Adjust volume.

3 /PAIRING
- Answer or reject an incoming call.
- End the current phone call.
- Disconnect Bluetooth connection.
- Enter Bluetooth pairing mode.

4 NFC
- Connect a device with NFC feature through Bluetooth.

5 AUDIO IN
- Connect an external audio device.

6 CHARGING 5V ⎓ 1A
- Charge your mobile devices.

7 DC IN
- Connect power.

3 Get started

Always follow the instructions in this chapter in sequence.

Connect power

Caution

- Risk of product damage! Make sure that the power voltage corresponds to the voltage printed on the back or underside of the speaker.

Connect the power adapter to:

- the **DC IN** socket on the speaker.
- the wall outlet.



Turn on

Press ⏻ to turn on the speaker.

↳ The speaker switches to Bluetooth mode automatically.

↳ The LED indicator flashes blue.

Turn off

The speaker is turned off in the following situations:

- Press ⏻ again; or
- The Bluetooth connection is disconnected and there is no audio-in cable inserted for 15 minutes.

↳ The LED indicator is turned off.

4 Use Bluetooth devices

With this speaker, you can listen to audio from Bluetooth-enabled devices and control the incoming call through Bluetooth.

Connect a device

Note

- Make sure that your Bluetooth device is compatible with this speaker.
- Before pairing a device with this speaker, read its user manual for Bluetooth compatibility.
- The speaker can memorize a maximum of 4 paired devices.
- Make sure that Bluetooth function is enabled on your device, and your device is set as visible to all other Bluetooth devices.
- Any obstacle between this speaker and a Bluetooth device can reduce the operational range.
- Keep away from any other electronic device that may cause interference.

Option 1: Connect a device through NFC

Near Field Communication (NFC) is a technology that enables short-range wireless communication between various NFC compatible devices, such as mobile phones and IC tags.
If your Bluetooth device supports NFC, you can connect it with this speaker easily.

1. On your device, enable NFC and Bluetooth functions (refer to the user manual of the device).
2. Press ⏻ on this speaker.
   ↳ The LED indicator flashes blue.
3. Touch the NFC tag on the top of the speaker with the NFC area of your Bluetooth device.



4. Follow the on-screen instructions to complete the pairing and connection.
   ↳ After successful connection, the speaker beeps twice, and the LED indicator turns solid blue.

Option 2: Connect a device manually

Note

- The operational range between this speaker and a Bluetooth device is approximately 10 meters (30 feet).

1. Press ⏻.
   ↳ The LED indicator flashes blue.
2. On your Bluetooth device, enable Bluetooth and search for Bluetooth devices that can be paired (see the user manual of the device).
3. When **[Philips BT4000]** is displayed on your device, select it to start pairing and connection. If necessary, input "0000" as the pairing password.
   ↳ After successful pairing and connection, the speaker beeps twice, and the LED indicator turns solid blue.

LED indicator	Description
Flashing blue	Connecting; Waiting for pairing
Solid blue	Connected

Play from Bluetooth devices

Note

- If there is an incoming call on the connected mobile phone, music play pauses.

After successful Bluetooth connection, play audio on the Bluetooth device.

↳ Audio streams from your Bluetooth device to the speaker.

Control your phone call

After Bluetooth connection, you can control an incoming call with this speaker.

Button	Function
	Press to answer an incoming call.
	Press and hold for two seconds to reject an incoming call.
	During a call, press to end the current call.

Note

- Music play pauses when there is an incoming call.

Disconnect the Bluetooth-enabled device

- Press and hold **PAIRING** for two seconds;
- Disable Bluetooth on your device; or
- Move the device beyond the communication range.
  ↳ The LED indicator flashes.

Connect another Bluetooth-enabled device

1 Press and hold **PAIRING** for two seconds to disconnect the currently connected device;
  ↳ The speaker enters Bluetooth pairing mode.

2 Connect another Bluetooth device.

Reconnect the Bluetooth device

- Next time you turn on the speaker, the speaker will reconnect the last connected device automatically; or
- On your Bluetooth device, select "**PHILIPS BT4000**" on your Bluetooth menu to start connection.

5 Other features

Listen to an external device

With this speaker, you can also listen to an external audio device such as an MP3 player.

Note

- Make sure that there is no Bluetooth connection, or music playback through Bluetooth is paused.

1 Connect an audio input cable (not supplied) with a 3.5 mm connector on both ends to
   - the **AUDIO IN** socket on this speaker, and
   - the headphone socket on the external device.

   ↳ The speaker switches to audio-in mode automatically.

2 Play audio on the external device (refer to its user manual).



Charge your mobile devices

You can charge your mobile devices through the USB socket.

Note

- The USB socket is for charging only.

1 Connect this speaker to AC power.
2 Connect this speaker to your mobile device with a USB cable (not supplied).

   ↳ Once the device is recognized, the charging starts.



Adjust volume

During play, press + or - repeatedly to increase or decrease the volume level.



Tip

- To increase or decrease volume continuously, press and hold + or - for 2 seconds.
- When the volume reaches the maximum or minimum, the LED indicator flashes twice.

6 Product information

Note

- Product information is subject to change without prior notice.

Specifications

Amplifier

Rated Output Power	2 X 10 W RMS
Frequency Response	80 -16000 Hz, ±3 dB
Signal to Noise Ratio	>67 dBA
Audio-in Input	600 mV RMS 20 kohm

Bluetooth

Bluetooth Version	V3.0
Supported Profiles	HFP, A2DP, AVRCP
Bluetooth Frequency Brand	2.4 GHz ~ 2.48 GHz
Bluetooth Range	10 m (Free space)

Speakers

Speaker Impedance	8 ohm
Speaker Driver	7cm full range
Sensitivity	>84dB/m/W ± 3dB/m/W

General information

AC Power	
(Power Adapter)	Brand name: PHILIPS;
	Model: AS360-120-AE250;
	Input: 100-240 V~, 50/60 Hz, 1.2 A
	Output: 12 V ⎓ 2.5 A;
Operation Power Consumption	12.5 W (with 1A charging loader)
Dimensions - Main Unit (W x H x D)	300 x 163 x 96 mm
Weight - Main Unit	1.7 kg

7 Troubleshooting

Warning

- Never remove the casing of this device.

To keep the warranty valid, never try to repair the system yourself.
If you encounter problems when using this device, check the following points before requesting service. If the problem remains unsolved, go to the Philips Web page (www.philips.com/support). When you contact Philips, make sure that the device is nearby and the model number and serial number are available.

General

No power

- Make sure that the AC power plug of the unit is connected properly.
- Make sure that there is power at the AC outlet.

No sound or poor sound

- Adjust volume on the product.
- Adjust volume on the connected device.

No response from the speaker

- Restart the speaker.

Cannot charge mobile devices

- Make sure that AC power is connected properly.
- Make sure that there is power at the AC outlet.

About Bluetooth device

The audio quality is poor after connection with a Bluetooth-enabled device.

- The Bluetooth reception is poor. Move the device closer to this product or remove any obstacle between them.

Cannot connect with the device.

- The Bluetooth function of the device is not enabled. Refer to the user manual of the device for how to enable the function.
- This product is already connected with another Bluetooth-enabled device. Disconnect that device and then try again.

The paired device connects and disconnects constantly.

- The Bluetooth reception is poor. Move the device closer to this product or remove any obstacle between them.
- For some devices, Bluetooth connection may be deactivated automatically as a power-saving feature. This does not indicate any malfunction of this product.

8 Notice

Any changes or modifications made to this device that are not expressly approved by WOOX Innovations may void the user's authority to operate the equipment.

Compliance

CE 0700

Hereby, WOOX Innovations declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. You can find the Declaration of Conformity on www.philips.com/support.

Care of the environment

Recycling

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.
When you see the crossed-out wheel bin symbol attached to a product, it means the product is covered by the European Directive 2002/96/EC:

Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health.

Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)
Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

Trademark notice

Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by WOOX Innovations is under license.

nfc

The N Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.

Specifications are subject to change without notice.
2014 © WOOX Innovations Limited. All rights reserved.
Philips and the Philips' Shield Emblem are registered trademarks of Koninklijke Philips N.V.
and are used by WOOX Innovations Limited under license from Koninklijke Philips N.V.

BT4000_12_UM_V2.0